



**Parts Book**


**Hydraulic Ride-on Power Trowel**

**CRT1046**






ITEM NO.	PART NO.	QTY	DESCRIPTION
1	G104601001	1	Joystick, Left
2	T104601001	2	Cover
3	00070006-16	4	Socket Head Screw, M6x16
4	00093006	4	Spring Washer
5	00095006	4	Washer
6	G104601002	2	Switch, Light
7	G104601003	1	Lock
8	00818005-10	4	Screw, M5x10
9	T104601002	1	Control Panel
10	T104601003	1	Joystick Holder, Left
11	T104601004	1	Cover, Joystic Holder, Left
12	G104601004	2	Lock
13	G104601005	1	Handle, Left
14	G104601006	1	Handle, Right
15	05783008-25	4	Hex Head Screw, M8x25
16	00093008	4	Spring Washer
17	00095008	4	Washer
18	05783008-35	8	Hex Head Screw, M8x35
19	00093008	8	Spring Washer
20	00095008	8	Washer
21	T104601005	1	Cover, Joystic Holder, Right
22	G104601007	1	Joystick, Right
23	05783006-16	4	Hex Head Screw, M6x16
24	00093006	4	Spring Washer
25	00095006	4	Washer
26	G104601008	1	Volt and Hour Meter
27	G104601009	1	Hydraulic Pressure Indicator
28	00818005-10	3	Screw, M5x10
29	T104601006	1	Joystick Holder, Right




**Hydraulic Ride-on Power Trowel Parts List****CRT1046**

ITEM NO.	PART NO.	QTY	DESCRIPTION
30	T104602001	1	Protective Plate, Right
31	00070006-12	4	Socket Head Screw, M6x12
32	00818006-20	4	Screw, M6x20
33	T104602002	2	Connecting Plate
34	G104602002	1	Cooling System
35	00095006	4	Washer
36	00093006	4	Spring Washer
37	06170006	4	Hex Nut, M6
38	G104602003	1	Hydraulic Oil Level Gauge
39	05783006-16	2	Hex Head Screw, M6x16
40	00093006	2	Spring Washer
41	00095006	2	Washer
42	G104602004	1	Filter
43	00923012	1	Nut, M12
44	00093012	1	Spring Washer
45	G104602005	1	Washer
46	G104602006	1	Hex Head Srew
47	G104602007	1	Tempreture Sensor
48	T104602003	1	Hydraulic Oil Tank
49	G104602008	1	Fuel Filter
50	06170008	8	Hex Nut, M8
51	00095008	8	Spring Washer
52	00093008	8	Washer
53	05783008-35	8	Hex Head Screw, M8x35
54	T104602004	1	Plate, Seat
55	G104602009	1	Oil Tank Cover
56	G104602010	1	Oil Pipe
57	G104602011	1	Lever, Oil Tank
58	G104602012	1	Oil Pipe
59	00818005-20	9	Screw, M5x20
60	00093005	9	Spring Washer
61	00095005	9	Washer
62	03452063	3	Oil Seal
63	T104602005	1	Oil Tank
64	00444018	1	Oil Plug
65	T104602006	1	Frame
66	00923008	8	Nut, M8
67	00093008	8	Spring Washer
68	00095008	8	Washer
69	05783008-90	8	Hex Head Screw, M8x90




ITEM NO.	PART NO.	QTY	DESCRIPTION
70	T104602006	2	Plate, Seat
71	00818005-10	64	Screw, M5x10
72	T104602007	1	Plate
73	G104602013	1	Valve
74	05783008-55	3	Hex Head Screw, M8x55
75	00095008	3	Washer
76	00093008	3	Spring Washer
77	06170008	3	Hex Nut, M8
78	T104602008	1	Plate, Seat
79	G104602014	1	Seat
80	T104602009	1	Hinge
81	T104602010	1	Proctive Frame, Engine
82	05783006-35	3	Hex Head Screw, M6x35
83	00095006	3	Washer
84	00093006	3	Spring Washer
85	06170006	3	Hex Nut, M6
86	00889012	2	Lock Nut, M12
87	05783008-25	4	Hex Head Screw, M8x25
88	00070012-75	2	Socket Head Screw, M12x75
89	00889008	4	Lock Nut, M8
90	G104602015	1	Cover, Water Tank
91	G104602016	1	Water Hose
92	G104602017	1	Gasket, Water Tank
93	T104602011	1	Water Tank
94	T104602012	4	Fixed Connector
95	05783008-40	4	Hex Head Screw, M8x40
96	05783008-20	4	Hex Head Screw, M8x20
97	00093008	8	Spring Washer
98	00095008	8	Washer
99	06170008	4	Hex Nut, M8
100	G104602018	1	Battery
101	G104602019	2	Screw
102	G104602020	1	Fixed Plate
103	00062006	2	Nut, M6
104	T104602013	1	Proctive Plate
105	G104602021	1	Lock Nut
106	00818004-10	4	Screw, M4x10
107	T104602014	1	Cover
108	G104602022	2	Hinge
109	00819005-16	8	Screw, M5x16




**Hydraulic Ride-on Power Trowel Parts List****CRT1046**

ITEM NO.	PART NO.	QTY	DESCRIPTION
110	G104603001	1	Hex Head Screw
111	00093016	1	Spring Washer
112	05783006-16	4	Hex Head Screw, M6x16
113	00093006	4	Spring Washer
114	00095006	4	Washer
115	T104603001	1	Cover
116	T104603002	1	Retaining Ring
117	T104603003	1	Bearing Cover
118	02766010	2	Bearing
119	00894050	1	Retaining Ring
120	G104603002	2	Spring
121	G104603003	2	Spring
123	T104603004	1	Bearing Holder
124	T104603005	1	Retaining Ring
125	G104603004	1	Belt
126	T104603006	1	Pulley
127	00077	1	Socket Head Screw
128	G104603005	2	Hex Head Screw
129	00093012	2	Spring Washer
130	00095012	2	Washer
131	T104603007	1	Connecting Plate
132	00070010-30	2	Socket Head Screw, M10x30
133	00093010	2	Spring Washer
134	00095008	1	Washer
135	00093008	1	Spring Washer
136	05783008-25	1	Hex Head Screw, M8x25
137	G104603006	1	Pump
138	G104603007	1	Engine, Kohler CH940
139	06170008	4	Hex Nut, M8
140	00093008	4	Spring Washer




**Hydraulic Ride-on Power Trowel Parts List****CRT1046**

ITEM NO.	PART NO.	QTY	DESCRIPTION
141	00095008	4	Washer
142	G104603008	1	Light, Back
143	00095008	1	Washer
144	00093008	1	Spring Washer
145	06170008	1	Hex Nut, M8
146	G104603009	1	Bracket
147	06170008	1	Hex Nut, M8
148	00093008	1	Spring Washer
149	00095008	1	Washer
150	T104603008	1	Engine Mounted Plate
151	06170012	1	Hex Nut, M12
152	T104603009	1	Engine Mounted Plate
153	05783008-30	2	Hex Head Screw, M8x30
154	00095010	4	Washer
155	00093010	4	Spring Washer
156	06170010	4	Hex Nut, M10




ITEM NO.	PART NO.	QTY	DESCRIPTION
157	00818005-25	6	Screw, M5x25
158	T104604001	1	Foot Pedal (Throttle Control)
159	00889006	2	Lock Nut, M6
160	00070008-25	2	Socket Head Screw, M8x25
161	T104604002	1	Plate
162	T104604003	1	Spring
163	00070008-25	2	Socket Head Screw, M8x25
164	T104604004	1	Throttle Control
165	T104604005	1	Foot Pedal
166	00889006	1	Lock Nut, M6
167	T104604006	1	Hook
168	00889006	1	Lock Nut, M6
170	00070008-25	1	Socket Head Screw, M8x25
171	06170008	1	Hex Nut, M8
172	T104604007	1	Safety Stop Switch
173	G104604001	1	Engine Stop Switch
174	T104604008	1	Foot Pedal
175	05789006-12	12	Hex Screw, M6x12
176	T104604009	1	Proctive Plate, Right
177	00095008	4	Washer
178	00093008	4	Spring Washer
179	00923008	4	Nut, M8
180	G104604002	2	Cover
181	05783010-35	4	Hex Head Screw, M10x35
182	00095010	4	Washer
183	00093010	4	Spring Washer
184	06170010	4	Hex Nut, M10
185	05789006-12	10	Hex Screw, M6x12
186	T104604009	1	Proctive Plate, Front
187	00095008	8	Washer
188	00093008	8	Spring Washer
189	05783008-20	8	Hex Head Screw, M8x20
190	06170010	4	Hex Nut, M10
191	00093010	4	Spring Washer
192	00095010	4	Washer
193	T104604010	2	Guard Ring




**Hydraulic Ride-on Power Trowel Parts List****CRT1046**


ITEM NO.	PART NO.	QTY	DESCRIPTION
194	05783010-55	4	Hex Head Screw, M10x55
195	05783010-55	4	Hex Head Screw, M10x55
196	G104604003	2	Light
197	T104604011	2	Bracket
198	00095008	4	Washer
199	00093008	4	Spring Washer
200	05783008-20	4	Hex Head Screw, M8x20
201	00095008	2	Washer
202	00093008	2	Spring Washer
203	06170008	2	Hex Nut, M8
204	T104604012	1	Logo Plate
205	00818006-16	4	Screw, M6x16
206	T104604013	1	Cover, Left
207	T104604014	2	Shaft
208	00879005-30	2	Pin
209	G104604004	2	Spring
210	00894027	2	Retaining Ring
211	T104604015	2	Rubber Cover
212	06170010	4	Hex Nut, M10
213	00093010	4	Spring Washer
214	00095010	4	Washer
215	T104604016	1	Frame
216	G104604005	2	Spray Nozzle
217	G104604006	2	Connector
218	05783008-80	1	Hex Head Screw, M8x80
219	T104604017	1	Connector Plate
220	00095008	1	Washer
221	00093008	1	Spring Washer
222	06170008	1	Hex Nut, M8
223	G104604007	1	Pump
224	06170005	4	Hex Nut, M5
225	00093005	4	Spring Washer
226	00095005	4	Washer
227	T104604018	1	Connector
228	00095008	2	Washer
229	00093008	2	Spring Washer
230	06170008	2	Hex Nut, M8




ITEM NO.	PART NO.	QTY	DESCRIPTION
231	T104605001	5	Screw
232	00889008	5	Lock Nut, M8
233	T104605002	5	Rubber Cover
234	00889010	5	Lock Nut, M10
235	00095010	10	Washer
236	G104605001	1	Cylinder
237	T104605003	5	Screw
238	T104605004	1	Bracket
239	00095010	2	Washer
240	00093010	2	Spring Washer
241	05783010-25	2	Hex Head Screw, M10x25
242	05783010-25	4	Hex Head Screw, M10x25
243	00093010	4	Washer
244	00095010	4	Spring Washer
245	05783012-30	8	Hex Head Screw, M12x30
246	00093012	8	Washer
247	00095012	8	Spring Washer
248	T104605005	1	Base Plate, Right
248-2	T104605006	1	Base Plate, Left
249	G104605002	4	Bearing Holder
250	05783012-65	8	Hex Head Screw, M12x65
251	00889012	8	Lock Nut, M12
252	G104605003	2	Shaft
253	T104605007	2	Yoke
254	00901012-60	10	Screw, M12x60
255	T104605008	1	Plate, Right
256	00095012	10	Washer
257	00093012	10	Spring Washer
258	06170012	10	Hex Nut, M12
259	G104605004	1	Cylinder
260	G104605005	1	Cylinder
261	T104605009	1	Gearbox Assy., Right
262	01096008-20	4	Key
263	00070008-20	8	Socket Head Screw, M8x20
264	T104605010	4	Flange




ITEM NO.	PART NO.	QTY	DESCRIPTION
265	G104605006	2	U-joint
266	05783014-45	4	Hex Head Screw, M14x45
267	G104605007	2	Bearing Holder
268	00095014	4	Washer
269	00093014	4	Spring Washer
270	T104605011	4	Hex Nut, M14
271	01096010-65	1	Shaft
272	T104605012	1	Key
273	T104605013	1	Pulley
274	T104605014	1	Bracket Assy., Left
275	T104605015	1	Gearbox Assy., Left
276	T104605016	1	Working System, Left
277	T104605017	1	Working System, Right
278	G104605008	1	Cylinder
279	T104605018	1	Bracket
280	G104605009	1	Cylinder






**Hydraulic Ride-on Power Trowel Parts List****CRT1046**

ITEM NO.	PART NO.	QTY	DESCRIPTION
281	00070008-25	20	Screw, M8x25
282	G104606001	2	Muffler
283	T104606001	2	Top Cover
284	T104606002	2	Gasket
285	03452212	2	Seal
286	00070008-25	1	Screw, M8x25
287	T104606003	2	Gasket
288	29730209	2	Bearing
289	T104606004	1	Worm Gear, Right
290	02766210	2	Ball Bearing
291	01096014-65	2	Key
292	T104606005	2	Worm Shaft
293	00070006-20	32	Socket Head Screw, M6x20
294	T104606006	2	Bearing Cover
295	T104606007	4	Gasket
296	03452080	4	Seal
297	29732207	4	Bearing
298	T104606008	1	Gearbox Case, Right
299	01096012-35	2	Key
300	T104606009	1	Shaft, Right
301	T104606010	2	Bearing Cover
302	13871035	2	Oil Seal
303	G104606002	2	Plug
304	07941027	2	Oil Gauge
305	00091025	4	Pin
306	00848010	4	Washer
307	04450012	2	Screw
308	00097012	2	Washer
309	13871045	2	Oil Seal
310	T104606011	2	Pin
311	T104606012	1	Worm Gear, Left
312	T104606013	1	Worm Shaft, Left
313	T104606014	1	Gearbox Case, Left





ITEM NO.	PART NO.	QTY	DESCRIPTION
314	T104607001	2	Stabilizer Ring
315	T104607002	2	Bearing Holder
316	T104607003	2	Bearing
317	T104607004	2	Blade Lifting Ring
318	CFB061816	10	Finishing Blade
319	00070008-12	10	Socket Head Screw, M8x12
320	T104607005	10	Trowel Arm Extended
321	00095008	40	Washer
322	00093008	40	Spring Washer
323	05783008-45	40	Hex Head Screw, M8x45
324	03452028	10	Seal
325	T104607006	5	Mount, Right
326	00879008-40	10	Pin
327	06170010	10	Hex Nut, M10
328	00012010-30	10	Screw, M10x30
329	07940010	10	Oil Cup
330	G104607001	10	Dust Cap
331	T104607007	5	Spring
332	T104607008	1	Spider Hub, Right
333	00070014-40	2	Socket Head Screw, M14x40
334	T104607009	2	Washer
335	T104607010	5	Mount, Left
336	T104607011	5	Spring
337	T104607012	1	Spider Hub, Left

---

[www.conmec.cn](http://www.conmec.cn)

**CONMEC ENGINEERING CO., LTD**

Add: No.88, 2# Industrial Avenue, Anwu Road, Wuqiao County, Fengxian District, Shanghai, P.R.C  
Tel: 86 (0)21 57407318 Fax: 86 (0)21 57406955 E-mail: [sales@conmec.cn](mailto:sales@conmec.cn)

Version: 20170101